KEEPING YOUR FACILITIES SAFE

APPENDIX A SAFETY FIRST FACILITY SAFETY SIGNS


S I N


Eyewash Station


rotection

Station











- Use on firm, flat floor or ground.
- Always use safety stands to hold up vehicle.
- Ensure that stands are placed on the vehicle frame and are set at the same height.



operation & safety procedures have been demonstrated.

- Never point an air nozzle at any part of your body or at anyone.
- Always wear safety glasses when using any tools that require compressed air to operate.



- Know how high you can safely raise a vehicle.
- Make sure vehicle is driven onto the hoist squarely.
- Lifting pads must be on the frame.
- Eye goggles must be worn when working below a vehicle.



operation & safety procedures have been demonstrated.

- Must be used on a flat ground surface.
- Must be placed on the frame, sub-frame, or vehicle suspension.




- Use with ventilation.
- Use latex gloves to protect hands.
- Wear eye protection.
- Do not use compressed air to dry a part.




- Remove any loose stones in tread.
- Make sure tire cover safety switch is working.
- Do not lift safety cover until tire has stopped rotating.
- Ensure floor area is dry.




- Eye protection must be worn.
- Avoid skin and mouth contact.
- Wash hands after using chemicals.
- Refer to MSDS binder for further information.




- Eye protection must be worn.
- Avoid skin and mouth contact.
- Wash hands after using chemicals.
- Refer to MSDS binder for further information.





- Avoid skin and mouth contact.
- Wash hands after using chemicals.
- Wash hands after using ink.
- Refer to MSDS binder for further information.





P7





- Handle or carry with sharp end pointing towards the floor.
- Hand or pass sharp objects handle first.
- Avoid touching sharp edges.




operation & safety procedures have been demonstrated.

- Avoid skin and mouth contact.
- Do not point the airbrush at anyone.
- Wash hands after using chemicals.
- Refer to MSDS binder for further information.







- Eye protection must be worn.
- Remove jewelry, eliminate loose clothing, and confine long hair.
- Operate only with guards in place.
- Do not wear gloves.



- operation & safety procedures have been demonstrated.
- Eye protection must be worn.
- Keep fingers and feet away from moving parts.



- Eye protection must be worn.
- Remove jewelry, eliminate loose clothing, and confine long hair.
- Operate only with guards in place.
- Always clamp material.
- Remove chuck key from chuck.



- Eye protection must be worn.
- Wear proper safety gear to avoid skin contact (e.g., gloves, apron).
- Refer to "Ferric Chloride" or "Ammonia Persulphate" in MSDS binder for further information.



- Eye protection must be worn.
- Remove jewelry, eliminate loose clothing, and confine long hair.
- Operate only with guards in place.
- Make all adjustments with the power off.
- Joint faces and edges only.
- Do not joint wood less than 12" long.
- Use a hold-down push block for jointing surfaces.



- Eye protection must be worn.
- Remove jewelry, eliminate loose clothing, and confine long hair.
- Operate only with guards in place.
- Check that wood is secure before starting.
- Position the tool rest to within 3 mm (1/8") of the wood.
- Remove the entire tool rest assembly before sanding.



- Eye protection must be worn.
- Remove jewelry, eliminate loose clothing, and confine long hair.
- Operate only with guards in place.
- Use a router bit guard whenever possible.
- Feed the material in the correct direction.

Safety FIRST THICKNESS PLANER

Operate only with teacher's permission, and only after operation & safety procedures have been demonstrated.

- Eye protection must be worn.
- Remove jewelry, eliminate loose clothing, and confine long hair.
- Operate only with guards in place.
- Do not plane wood less than 12" long.
- If wood gets stuck, turn off power then lower the table.
- Check wood for loose knots and foreign materials before planing.



- Eye protection must be worn.
- Remove jewelry, eliminate loose clothing, and confine long hair.
- Operate only with guards in place.
- Lower the guard to within 3 mm (1/8") of the wood.
- Keep hands 5 cm (2") away from the cut line.
- Cut slowly without forcing the material.

Safety FIRST COMPOUND MITRE SAW

Operate only with teacher's permission, and only after operation & safety procedures have been demonstrated.

- Eye protection must be worn.
- Remove jewelry, eliminate loose clothing, and confine long hair.
- Operate only with guards in place.
- Secure wood against fence.
- Allow the saw blade to reach maximum speed before it contacts the wood.
- Keep hands a safe distance from the blade (15 cm [6"] away).



- Eye protection must be worn.
- Remove jewelry, eliminate loose clothing, and confine long hair.
- Operate only with guards in place.
- Secure wood against the fence.
- Pull saw forward with a controlled speed.
- Keep hands 12" away from the blade.




- Eye protection must be worn.
- Remove jewelry, eliminate loose clothing, and confine long hair.
- Operate only with guards in place.
- Always use a fence or mitre guide.
- Never stand directly in line with the saw blade.



- Eye protection must be worn.
- Remove jewelry, eliminate loose clothing, and confine long hair.
- Ensure that the pressure foot is resting on the wood.
- Cut slowly, guiding the wood gently with thumbs and fingers.
- Keep hands a safe distance from the blade—never directly in front.



- Eye protection must be worn.
- Remove jewelry, eliminate loose clothing, and confine long hair.
- Operate only with guards in place.
- Feed wood against the rotation of the cutters.



- Eye protection must be worn.
- Remove jewelry, eliminate loose clothing, and confine long hair.
- Feed wood in the direction opposite to the direction that the spindle turns.
- Use the smallest table insert that can surround the spindle.
- Press wood lightly against the spindle.
- Keep wood tight against the tabletop.



- Eye protection must be worn.
- Remove jewelry, eliminate loose clothing, and confine long hair.
- Tightly secure all materials to the table when drilling.
- Never drill metals without proper clamps.
- Adjust table height and make depth adjustments before power is turned on.



- Eye protection must be worn.
- Remove jewelry, eliminate loose clothing, and confine long hair.
- Hold wood flat against the tabletop.
- Press wood lightly against the belt/disk.
- Call the teacher if the belt is not tracking straight.

Safety FIRST MORTISING MACHINE

Operate only with teacher's permission, and only after operation & safety procedures have been demonstrated.


- Eye protection must be worn.
- Remove jewelry, eliminate loose clothing, and confine long hair.
- Keep a slight gap between the hollow chisel and the bit to avoid overheating.
- Tightly secure wood to the tabletop.
- Make all table and depth adjustments with the power off.



- Eye protection must be worn.
- Remove jewelry, eliminate loose clothing, and confine long hair.
- Operate only with shield in place.
- Keep the tool rest within 3mm (1/8") of the grindstone.
- Do not grind against the side of the stone.




- Eye protection must be worn.
- Remove jewelry, eliminate loose clothing, and confine long hair.



- Eye protection must be worn.
- Remove jewelry, eliminate loose clothing, and confine long hair.
- Operate only with shield in place.
- Apply work only to the lower part of the wheel.
- Do not wear gloves.



- Eye protection must be worn.
- Remove jewelry, eliminate loose clothing, and confine long hair.
- Only use hand tools for the job they were designed to do.
- Never use cheater bars, handles, or pipes to gain additional leverage.



- Eye protection must be worn (e.g., face shield).
- Wear proper safety gear (e.g., apron, gloves).
- Remove jewelry, eliminate loose clothing, and confine long hair.
- ONLY the instructor pours molten metal.





- Eye protection must be worn (e.g., helmet).
- Wear proper safety gear (e.g., gloves, apron).
- Remove jewelry, confine long hair.
- No nylon or loose clothing.
- Make sure area is well ventilated.




operation & safety procedures have been demonstrated.

- Eye protection must be worn.
- Remove jewelry, eliminate loose clothing, and confine long hair.









- Eye protection must be worn (e.g., face shield).
- Wear proper safety gear (e.g., gloves, apron).
- Remove jewelry, eliminate loose clothing, and confine long hair.



- Eye protection must be worn (e.g., goggles with a #5 lens).
- Wear proper safety gear (e.g., gloves, apron).
- Remove jewelry, eliminate loose clothing, and confine long hair.
- Make sure area is well ventilated.
- Do not exceed 15 psi on acetylene regulator.



- Eye protection must be worn (e.g., welding helmet).
- Wear proper safety gear (e.g., gloves, apron).
- Remove jewelry, eliminate loose clothing, and confine long hair.
- Make sure area is well ventilated.



- Eye protection must be worn.
- Remove jewelry, eliminate loose clothing, and confine long hair.
- Remove chuck key from chuck.
- Start at low speed.
- Ensure work is securely in the chuck or between centres before starting.





- Keep floors free of debris.
- Clean up messes/spills immediately.
- Use "floor-dry"/absorb-all" for oil-based spills.
- Use plenty of water for acid spills.
- Refer to MSDS binder for further information regarding spills/clean-ups.